PIG Absorb-&-Lock™ Water Absorbent Strips

Deploy New Pig's super absorbent water strips to absorb high volume leaks and seeps before they turn into a safety hazard. These strips are designed to soak up to 5 litres of water quickly and lock it in for a mess-free clean up. A low-profile design makes them ideal for tight places, while a printed safety message draws awareness. Be sure to inspect area regularly and remove when product is fully swelled.

Instructions

Step 1: Place low-profile Absorb-&-Lock Water Absorbent Strips in areas where water leaks or overhead drips are common. To ensure proper absorbency, make sure strip is flat on the floor. **(fig. A)**

Step 2: Leave strip down until fully saturated with water. Product swells up to 7,6cm thick when full. **(fig. B)**

Step 3: Routinely inspect your Absorb-&-Lock Water Absorbent Strips for timely change outs.

Step 4: Products are non-hazardous. Dispose in standard waste or per your internal waste stream management process. Do not drag or drop strips. A fully saturated sock can weigh from 5kg (152cm strip) up to 10kg (305cm strip). (**fig. C**)

Step 5: Be sure to wipe surface dry once strip is removed and reapply if necessary.

NOTE: Account for swelling if using in low-profile applications.





